



NOW STRIP THE INSULATION OF THE DIELECTRIC



YOU SHOULD NOW HAVE THE CENTRE CONDUCTOR EXPOSED



NOW PUSH THE CENTRE CONDUCTOR INTO BNC



NOW PUSH BRAID OVER BNC



NOW PUSH THE CENTRE CONDUCTOR INTO BNC



NOW FINALLY CRIMP SLEEVE TO BNC